

# The BLUEVIEW<sup>®</sup> Access Control Software

*By using open standards Wi-Fi and Ethernet networks, BlueWave allows the system to be managed and monitored using IT network tools from any vendor.*

BlueView Professional access control software is used to configure, administer and monitor NetGen door controllers and Wi-Fi enabled, battery-powered locks.

## System Requirements (Express and Professional Editions \*)

- Microsoft Windows XP SP3 or Higher
- – 64-bit support on Microsoft Windows 7 or Higher
- Microsoft SQL Server 2005 or Higher (Express or Standard)
- Minimum RAM: 2GB or greater
- Hard Disk: Minimum of 500MB for BlueView database (database will grow with usage)

\* Enterprise-level installations may require significantly greater resources. Please contact BlueWave Security for more information.

|                                   | TRIAL           | EXPRESS           | PROFESSIONAL       | ENTERPRISE     |
|-----------------------------------|-----------------|-------------------|--------------------|----------------|
| Part #                            | BVTri (30 days) | BVExp             | BVPro              | BVEnt          |
| # of Doors                        | <5              | <30               | <60                | Unlimited      |
| # of Clients                      | 0               | 0                 | 5                  | Unlimited      |
| # of Users                        | 3               | 3                 | 5                  | Unlimited      |
| # of Cardholders                  | 500             | 500               | 1,000              | Unlimited      |
| SYSTEM EXPANSION                  |                 |                   |                    |                |
| Additional (5) Software Licenses  |                 | √ (doors 6 to 30) |                    | Unlimited      |
| Additional (10) Software Licenses |                 |                   | √ (doors 11 to 60) | Unlimited      |
| MODULES                           |                 |                   |                    |                |
| Active Directory                  |                 |                   | √ <sup>1</sup>     | √ <sup>1</sup> |
| Video Module                      |                 |                   | √ <sup>1</sup>     | √ <sup>1</sup> |
| Import Cards Utility              | √               |                   | √                  | √              |
| PRODUCT INTEGRATION               |                 |                   |                    |                |
| BluePass                          | √               | √                 | √                  | √              |

√ = denotes AVAILABLE.

√<sup>1</sup> = Additional module customized to end user legacy system specifications.

*Note: Software part#'s and current software version features on back*



The IP and Wi-Fi Access Control Company

2270 Camino Vida Roble  
Carlsbad, CA 92011

Tel: 760-929-9596  
Email: [Sales@BlueWaveSecurity.com](mailto:Sales@BlueWaveSecurity.com)

Distributed by:



# The BLUEVIEW<sup>®</sup> Access Control Software

**Current Software Version:** Eff. 12/13\_\_15.2.5085.27485

## New Features Include:

- ☒ Expanded Compatibility & Support with: Microsoft SQL Server 2012, Microsoft Windows Server 2012, Microsoft Windows 8 and Microsoft Active Directory
- ☒ Enhanced Install Experience: Door Discovery with Integrated Device Installer and Database Configuration Wizard
- ☒ Improved Maintenance: Enhanced Overview Screen and Upgrade Path

|               |  |
|---------------|--|
| BVEXP         | BlueView Express Software*                                     |
| BVEXP-5       | BlueView Express Software (5 Door License)*                    |
| BVPRO         | BlueView Professional Software (15.2)                          |
| BVPRO-UPGRADE | BlueView Professional Upgrade to 15.2 (only for version 15)*** |
| BVPRO-10      | BlueView Professional Software (10 Door License)*              |
| BVENT         | BlueView Enterprise Software**                                 |
| BVPRO-AD      | BlueView Professional ACTIVE DIRECTORY Module*                 |
| BVPRO-VM      | BlueView Professional VIDEO Module*                            |

\* See Software Matrix for Details & Descriptions

\*\* Call for Factory Pricing

\*\*\* Free upgrade to 15.2 only for current version 15 BlueView Professional

## Download Software/ 15.2 Upgrade:

<http://www.bluewavesecurity.com/downloads>

**BLUEWAVE security**

Download Software

Home News Products Partners Solutions Support Training Company Contact Us

Home » BlueView Software Download

### BlueView Software Download

\*\*\* BlueView 15.2 Now Available! \*\*\*

- 1) Call BlueWave Security at 760.929.9596 to get login credentials to download the software.
  - Upgrading from BlueView 15.0 or 15.1? Upgrade for FREE!
  - Upgrading from BlueView 14 or earlier? Ask us about our special upgrade pricing!
- 2) Click [HERE](#) to download the BlueView software installation package. You will be prompted to enter the user name and password obtained above (Step 1).
- 3) Unzip the downloaded file and double-click on BlueView\_v15.2.xxxx.xxxx.exe to start the installation.
- 4) Refer to the BlueView15ReadMe file (included in the installation package) for more information about installation and links to additional software downloads.

Distributed by  
**Accu-Tech<sup>®</sup>**  
We're Known by the Companies We Keep

**BLUEWAVE security**

The IP and Wi-Fi Access Control Company

2270 Camino Vida Roble  
Carlsbad, CA 92011

Tel: 760-929-9596  
Email: [Sales@BlueWaveSecurity.com](mailto:Sales@BlueWaveSecurity.com)

To order, contact your local Accu-Tech representative.  
Visit us online at [www.accu-tech.com/contact-accu-tech/](http://www.accu-tech.com/contact-accu-tech/)